UNIVERSAL LI-ION BATTERY CHARGER
COMPATIBILITY CHART

BRAND	BATTERY	CHARGE BY
ANSMANN	A-Pan CGA S004E	Universal Plate
	A-Son NP FR 1	Universal Plate
	A-Son NP FT 1	Universal Plate
CANON®	BP-2L12/2LH	Universal Plate
	BP-208	Universal Plate
	BP-3LCL	Universal Plate
	BP-308/315	Universal Plate
	BP-406/407	Universal Plate
	BP-412/422	Universal Plate
	BP-511/512/522/535	Base Unit
	BP-608/617	Universal Plate
	BP-911/914/915/941	Base Unit
	BP-924/927/930/945	Base Unit
	NB-1L/1LH	Universal Plate
	NB2F12/NB-2LH	Universal Plate
	NB-2L/3L/4L	Universal Plate
CASIO®	NP-20/30/40	Universal Plate
FUJI®	DR-LB4	Universal Plate
	NP-30/40/60/80/95	Universal Plate
	NP-100/120	Universal Plate
GPI	VCL011	Universal Plate
	VFL001	Universal Plate
	VKL001	Universal Plate
	VNL002/004	Universal Plate
HAMA	CP846	Universal Plate
	DP-312	Universal Plate
HATICHI®	DZ-BP21S	Universal Plate
	VM-BPL13/27/30/60	Base Unit
	VM-E330/535	Base Unit
	VM-N520/NP500	Base Unit
JVC®	BN-507/514	Universal Plate
	BN-V101	Universal Plate
	BN-V107/V114	Universal Plate
	BN-V214/207	Universal Plate
	BN-V306/V37U	Universal Plate
	BN-V312/V312U	Universal Plate
	BN-V408/416/428	Base Unit
	BN-V607/ 615/628	Universal Plate
	BN-V712/714	Universal Plate
	BN-V812/814	Base Unit
	BN-V907	Universal Plate
	BN-VF707/VF714	Universal Plate
	BN-VF733	Universal Plate
	J-I723	Universal Plate
KODAK®	KLIC-3000	Universal Plate
	KLIC-5000/5001	Universal Plate
	KLIC-7000/7001	Universal Plate
	KLIC-7002/7003	Universal Plate
	KLIC-7004/7005	Universal Plate
	KLIC-7006/7008	Universal Plate
KONICA MINOLTA®	DR-LB1/LB4	Universal Plate
	NP-1L	Universal Plate
	NP-200/400/500	Universal Plate
	NP-600/700/800	Universal Plate
	NP-900	Universal Plate
KYOCERA®	BP-780S/800S	Universal Plate
	BP-1000S/1100S	Universal Plate
NIKON®	EN-EL1/EL2 /EL3	Universal Plate
	EN-EL5/EL8	Universal Plate
OLYMPUS®	BP-LM1	Universal Plate
	LI-10B/12B/20B	Universal Plate
	LI-40B/42B	Universal Plate
	PS-BLM1	Universal Plate
PANASONIC®	AG-BP15P/BP25	Base Unit
	CGA-DU07/14/21	Universal Plate
	CGA-S001E/S002	Universal Plate
	CGA-S003A/1B	Universal Plate
	CGA-S004/S005	Universal Plate
	CGA-S006E	Universal Plate
	CGA-S301/S302A	Universal Plate
	CGP-110E/120E	Universal Plate
	CGP-145/165/285	Universal Plate
	CGP-D14/16/21/28	Universal Plate
	CGR-101	Universal Plate
	CGR-602A/602E	Universal Plate
	CGR-B202A	Base Unit
	CGR-D08A	Universal Plate
	CGR-D105	Universal Plate
	CGR-D110	Universal Plate
	CGR-D120	Universal Plate
	CGR-D16A	Universal Plate
	CGR-D210/D320	Universal Plate
	CGR-D220	Universal Plate
	CGR-D28A/D53A	Universal Plate
	CGR-S101A/S301A	Universal Plate
	CGR-S602A/S602E	Universal Plate
	CGR-V14/26	Universal Plate
	CGR-V610/620E	Universal Plate
	DMW-BC7	Universal Plate
	DMW-BCA7	Universal Plate
	DMW-BCB7	Universal Plate
	DMW-BCC12	Universal Plate
	DMW-BCD10	Universal Plate
	DMW-BL14	Universal Plate
	DMW-BM7	Universal Plate
	DMW-BMA7	Universal Plate
	PV-DBP5	Base Unit
	RP-BP30L/BP40L	Universal Plate
	VW-VBA05/10	Universal Plate
	VW-VBAP10	Universal Plate
	VW-VBD07	Universal Plate
	VW-VBD1 / E	Base Unit
	VW-VBD14	Universal Plate
	VW-VBD2	Base Unit
	VW-VBD21/23/24	Universal Plate
	VW-VBP10	Universal Plate
PENTAX®	D-L12/17/18	Universal Plate
POLAROID®	PR-105DG	Universal Plate
	PR-110DG/111DG	Universal Plate
RCA®	BB-065L	Base Unit
	BB-075/075L	Universal Plate
RICOH®	DB-30/40/43/60	Universal Plate
	NP-40	Universal Plate
SAMSUNG®	SB-L160/L320/L480	Base Unit
	0737	Universal Plate
	1137	Universal Plate
SANYO®	DB-L10/L20	Universal Plate
	UR-211	Universal Plate
	UR-421	Universal Plate
	VM-LC100	Base Unit
SHARP®	AD-S30BT/S31BT	Universal Plate
	AD-T50BT/T51BT	Universal Plate
	BT-L1/L2	Universal Plate
	BT-L11/L12/L22	Universal Plate
	BT-L221/L441/L241	Universal Plate
	BT-L225U	Universal Plate
	BT-L31/L41	Universal Plate
	VR-BL71/BL72/BL75	Universal Plate
	VR-BL81/BL91	Universal Plate
SONY®	LIP-10	Universal Plate
	LIP-4WM	Universal Plate
	LIP-880PD	Universal Plate
	NP-500/520	Base Unit
	NP-530	Universal Plate
	NP-BG1	Universal Plate
	NP-F10/F20/F30	Base Unit
	NP-F100/F200/F300	Base Unit
	NP-F330/F530	Base Unit
	NP-F550	Base Unit
	NP-F720/F730	Base Unit
	NP-F730H	Base Unit
	NP-F750/F750SP	Base Unit
	NP-F930	Base Unit
	NP-F950/F960	Base Unit
	NP-FC10/FC11	Base Unit
	NP-FE1	Universal Plate
	NP-FF50/70	Base Unit
	NP-FM50/70/90	Base Unit
	NP-FP50/70/90	Base Unit
	NP-FR1	Universal Plate
	NP-FS11/21/31	Base Unit
	NP-FT1	Universal Plate
	NP-QM51/71/91	Base Unit
THOMSON®	BAT600	Base Unit
TOSHIBA®	GSC-BT5	Universal Plate
	PDR-BT1/BT2	Universal Plate
	PDR-BT3/BT9	Universal Plate

All brands are the property of their respective owners.